

R100 Firmware V1.59 Update List:

1. Added ISO DST Support.
2. Added SMB Support.
3. Added Pre-out / Line-Out Switch.
4. Improved Bluetooth Transmitter function.
5. Added Maximum volume, Boot volume settings.
6. Optimized Album cover display and added Album cover/Lyrics download function.
7. Added Folder Copy function.
8. Added Search function for local files.
9. Adjusted Main Menu.
10. Adjusted sorting of Japanese alphabet (Active when using Japanese system language).
11. Optimized NAS and DLNA functions.
12. Optimized Wireless Projection performance.
13. Optimized SyncLink performance.
14. Updated Streaming apps, adding support for Apple Music.
15. Other bug fixes.

How to update:

Over-the-Air firmware update

1. Make sure your R100 is connected to a Wi-Fi network with access to internet.
2. Go to "Settings" - "Firmware Update".
3. Click on "Online Update" and wait for system to detect the new firmware.
4. Confirm and wait until firmware is downloaded and fully installed.

5. Go to System settings – Factory Data Reset and click on “Erase Everything” to perform full factory reset of the device.

Manual Update

1. Download firmware file [from Google Drive](#)
2. Copy downloaded .zip file onto a USB drive and insert it into USB1 or USB2 input. *(Do not unpack/open the .zip file)*
3. Go to "Settings" - "Firmware Update" and click on "Local Update".
4. Locate the update .zip file on the USB Drive.
5. Confirm install and wait until R100 updates and restarts itself.

6. Go to System settings – Factory Data Reset and click on “Erase Everything” to perform full factory reset of the device.