

Eddict Player App – Using SyncLink remote controls with desktop streamers

iOS version at Apple App Store:

<https://apps.apple.com/us/app/eddict-player/id1529232239>

Android version at Google Play Store:

<https://play.google.com/store/apps/details?id=com.shanling.eddictplayer>

How to set-up SyncLink remote control

1. Turn on Bluetooth on your phone and on STREAMER.
2. On STREAMER, go to "Network Service" and enable the "SyncLink".
3. On your phone, open Eddict Player app. In main menu, swipe right to view additional features. Click on "SyncLink".
4. Turn on the "SyncLink Controller" option.
5. App will scan for your STREAMER, it should show up in "Available device". Click on the STREAMER to get them paired.
6. Your phone will display message to confirm pairing. Firstly, go to your STREAMER, swipe down from top of the screen to view system notifications, open the pairing notification and confirm it. Now confirm pairing on your phone.
Pairing confirmation is only needed when using SyncLink for the first time. After this it will connect automatically once you open SyncLink option in Eddict app.
7. Once both devices are linked, you can return to main screen of Eddict player app and access the "Local Music", "Playlist" and "Recently Played" options. This provides you with simplified playback control over locally stored files on your STREAMER.
8. With Android phones, you can control volume from Eddict player app, just make sure STREAMER is set to Pre-Out mode, not Line-out mode. Not supported on iOS.
9. To turn off SyncLink on your phone, close the app.